



2023 KTM/Husqvarna Linkage Guard Install

1. The Bolt right side remains in shock(the previous year's it was removed, but not anymore; it stays in the shock)
2. Slide the right side Linkage Guard up around the shock.
3. Slide the left side link guard up around the shock.
4. Then, using supplied M8x30mm SHCS, apply Loctite to it and tighten the Linkage Guard together.

