



KTM 790/890 Case Saver Installation KTM 790/890 Adventure R&S all years
KTM 790/890 Duke all years

1. Remove existing stock plastic sprocket cover.
2. Install shift sensor guard using stock hardware (Loctite bolts)
3. Install Case Saver with provided M5X40 bolts (Loctite bolts)
4. Install chain slider with short end facing forward using supplied M8x40mm SHCS (Loctite bolts)

