



Bullet Proof Designs  
500 S Lincoln Ave  
Raymore MO 64083  
(816) 695-3784  
[www.bulletproofdesigns.com](http://www.bulletproofdesigns.com)

**FITMENT:**

These instructions apply to all BPD swingarm guards, all makes and models

- 1. Remove chain guide bolts**
- 2. Mount swingarm guard using supplied M6 bolts (Loctite)**

