



Yamaha WR/YZ, Kawasaki KX
Radiator Guards installation instructions

1. Remove side shrouds.
2. Remove stock louvers. Remove stock bolts from radiators.
3. Install radiator guards on radiators. Use stock bolts for inside mounting, use provided M6x16 BHCS for outside. (as shown in picture). Start both inside and outside bolts, than tighten all four bolts (this will align the outside radiator tabs).



4. Remove lower outside bolt "A" (shown in pic). The taped hole in the guard will be used to mount the side shrouds.
5. Re-install your radiator shrouds and your install is complete.

If you have any questions or comments on installation, call Nate at 816-695-3784