

Yamaha WR250 R/X Radiator Guards installation instructions

1. Remove seat and right side radiator shroud
2. Remove stock louvers from front of radiator (leave the rear fan shroud in place). Remove radiator mounting bolts/nut from radiators.
3. Install radiator guard on radiator. Use stock nut on top and supplied M6x30mm bolt on bottom for inside mounting, use provided M6x16 BHCS for outside. Start both inside and outside bolts, then tighten all four bolts.
4. The fan shroud will have to be notched in a couple spots to clear the guard (see pictures for areas to be cut).
5. Re-install shroud and seat

