



Bullet Proof Designs
500 S Lincoln Ave
Raymore, MO 64083
(816) 695-3784

FITMENT:

Fits most aluminum handlebars (Not for use on Renthal Twinwall or Azonic Double Wall handlebars).

- 1. Tap handlebar with 5/8-11 tap. If using supplied tap, leave 5-6 threads on tap for correct depth.**
- 2. Install bar end with Loctite using flat blade screw driver. Recommended to allow Loctite to dry before installing bar ends.**

Tips: Make sure tap starts straight. Adjustable wrench or socket can be used if tap handle is not available. Grease works well as tap lubricant and will remove chips.

